

REPLACEMENT PARTS LIST

Item No.	TE Part Number	Description	TEBQ 30G	TEBQ 30R	TEBQ 36G	TEBQ 36R	TEBQ 42G	TEBQ 42R	TEBQ 54R	
72	S13235Y	Knob Assembly	3	3	3	3	4	4	6	
73	S15303	Regulator, NG	1	1	1	1	1	1	1	
74	S15302	Regulator, LP	1	1	1	1	1	1	1	
75	S13301	U6-Burner	2	2			3	3	3	
76	S13350	U5-Burner			3	3				
77	S13345Y	Sear Burner Assembly (Optional Addition), with screen	1	1	1	1	1	1	1	
78	S13144	Mesh Screen for Sear Burner	1	1	1	1	1	1	1	
79	S16322Y	Hot Surface Igniter, Rotisserie, with screw		1		1		1	1	
80	S26334	I.R. Igniter Hood - LH		1		1		1	1	
81	S26377	I.R. Igniter Hood - RH							1	
82	S26306	Bracket, Warming Rack Stowed	2	2	2	2	2	2	2	
83	S14340	Hood Sleeve	2	2	2	2	2	2	2	
84	S14303	.250 X 1.750 SS Hex Head Screw	2	2	2	2	2	2	2	
85	S26307	Bracket, Warming Rack HI/LOW Position	2	2	2	2	2	2	2	
86	S26310	Spacer Plate, Rotis Rollers		4		4		4	4	
87	S14420	Roller Bearing		4		4		4	4	
88	S21750Y	Flash Tube Assembly, with screws	2	2	3	3	3	3	3	
89	S16386	Terminal Block	1	1	1	1	1	1	1	
90	S	Plug, 1/4	1	1	1	1	1	1	1	
91	S26372	Terminal Block Cover	1	1	1	1	1	1	1	
92	S16321Y	Igniter, Main Burners, with screw	2	2	3	3	3	3	4	
93	S26344	Ignition Cover	2	2	3	3	3	3	4	
94	S21765Y	Flash Tube Assembly (Optional Sear Burner Only)	1	1	1	1	1	1	1	
95	S26326-30	Lower Front Air Baffle (30")	1	1						
96	S26326-36	Lower Front Air Baffle (36")			1	1				
97	S26326-42	Lower Front Air Baffle (42")					1	1		
98	S26326-54	Lower Front Air Baffle (54")							1	
99	S15110-41	Orifice, #41 NG (Main Burner)	2	2	3	3	3	3	4	
100	S15110-53	Orifice, #53 LP (Main Burner)	2	2	3	3	3	3	4	
101	S15121	Microswitch, Valve Burner	2	2	3	3	3	3	4	
102	S12601	Elbow, 375CC x 125FIP		1		1		1	1	
103	S15149Y	Valve Burner	2	2	3	3	3	3	4	
104	S12734	Manifold (30")	1	1						
105	S12736	Manifold (36")			1	1				
106	S12735	Manifold (42")					1	1		
107	S12745	Manifold (54")							1	
108	S26319-30Y	Drip Pan Assembly (for Grills with Hidden Rotis)		1						
109	S26319-36Y	Drip Pan Assembly (for Grills with Hidden Rotis)				1				
110	S26319-42Y	Drip Pan Assembly (for Grills with Hidden Rotis)					1			
111	S26319-54Y	Drip Pan Assembly (for Grills with Hidden Rotis)							1	
112	S12606	Plug, 1/8	*	*	*	*	*	*	*	
113	S21761Y	5" Briquette Tray Assembly			2	2				
114	S21759Y	10" Briquette Tray Assembly			2	2				
115	S22735Y	Smoker Box Assembly (30", 42", 54")	1	1			1	1	1	
116	S22737Y	Smoker Box Assembly (36")			1	1				
117	S21752Y	6" Briquette Tray Assembly	2	2			2	2	2	
118	S21753Y	12" Briquette Tray Assembly	1	1			2	2	2	
119	S21743	Zone Divider	1	1	2	2	2	2	3	
120	S13875	10 9/16" SS Hex Grate			3	3				
121	S13802	12" SS Hex Grate					1	1	2	
122	S13801	13" SS Hex Grate	2	2			2	2	2	
123	S13330	I.R. Burner Small		1		1			2	
124	S13331	I.R. Burner Large						1		
125	S26300-30	Rear Hood Cover (30")	1	1						
126	S26300-36	Rear Hood Cover (36")			1	1				
127	S26300-42	Rear Hood Cover (42")					1	1		
128	S26300-54	Rear Hood Cover (54")							1	
129	S15151Y	Rotis Valve Burner		1		1		1	2	
130	S12665	Plug, Hex Socket, 1/4 NPT	1	1	1	1	1	1	1	
131	S26332-30	Drip Pan Assembly (30") (for G Model)	1							
132	S26332-36	Drip Pan Assembly (36") (for G Model)			1					
133	S26332-42	Drip Pan Assembly (42") (for G Model)					1			
134	S13260	Rotis Bezel Housing Assembly		1		1		1	2	
135	S26311	Plate, Chain Cover		1		1		1	1	
136	S26807Y	Sprocket Assembly		1		1		1	1	
Non-Shown Parts										
	S13129-12	Briquettes (12 pack)	(4)	(4)	(6)	(6)	(6)	(6)	(6)	
	S16391	12V Harness	1	1	1	1	1	1	1	
	S16392	110V Harness		1		1		1	1	
	S16006	8" Bezel Loop Harness		2		2		2	4	
	S16007	14" Bezel Loop Harness	1		2	1	2	1	1	